## Wireless Fire Alarm System Range 1 to 5 Km

## 99 Zome Alarm

The detectors can automatically match codes with alarm host. It's simple and fast.

- (1) 1-99 independent wireless zones can be armed or disarmed independently. Common zone and emergency zone can be defined at will.
- (2) Two groups of timer-open /close-timer can be set ,and it also indicate the current status.
- (3) Three kinds of alarm sound and four levels of alarm volumes are optional.
- (4) 10 pieces of latest alarm massages can be scroll display simultaneously.
- (5) 60 pieces of latest alarm messages can be inquired.
- (6) A group of normal open, a group of normal close and + 12V DC outputs are provided to control other devices (e.g., startup alarm siren, alarm light, alarm linkage etc.)
- (7) Rechargeable backup Battery (12V1.2Ah) is optional.

## 999 Zome Allarm

- (1) It has 1-999 independent wireless zones. Each can be armed or disarmed independently. It also can be defined to common zone and emergency zone independently.
- (2) The code of detector or wireless emitter can be learned to alarm host automatically or trigger by hand.
- (3) Super- large LED display and voice guide make alarm more humanly and easily.
- (4) Two access codes (installer code and user code) manage separately, and the code is modifiable to prevent program from distorting at ill will.
- (5) The alarm host has two timers. It can recognize on/off state automatically, and also indicates present (on/off) state.
- (6) Five pieces of up-to date alarm message can be scroll to display simultaneously.
- (7) Inquiring 100 pieces of up-to-date records (including alarm message and indicate message)
- (8) A normal open/close output and +12V DC output are provided to control other devices (e.g. startup alarm siren, alarm light, alarm linkage etc.)
- (9) Provide a set of audio signal output, which can connect directly with 8Ω15W passive trumpet and active sound box, and build-in trumpet loses affection automatically. (optional)
- (10) Micro printer can print 5 pieces of alarm records simultaneously, and also can print them one by one.(optional)
- (11) Manage center online can be connected with computer by RS232 interface and ready to display and manage the alarm message.
- (12) The internal or external backup battery are optional. There is protection for over-charged or over-discharged and also low power alert.
- (13) Rechargeable backup battery (12V 7Ah) is optional.
- (14) Dial module is optional.
- (15) Print module is optional.
- (16) Real Time Module is optional

